

Cuddly Calming Electronic Heartbeat Plush Dog Toy Instruction Manual

Sku: 1080558

frisco
by chewy

Please Read Through All Instructions Before Starting

Important Safety

WARNING: Please read all safety and product information below before using your Frisco product. Failure to follow these safety instructions could result in injury to you, your pet and others, or it could result in damage to your Frisco product or other property.

Parts Included



Cuddle
Plush Toy



Rechargeable
Heartbeat Mechanism



USB-C Charging
Cable

Charging Instructions

Charge the non-replaceable lithium-ion battery with a DC 5V/1A output charger for 60 minutes. A wall charger is not provided, only the USB charging cable. The battery must be fully charged before first use.

A red light means the product is charging. Once the light turns off, the battery is fully charged.



Introducing Your Puppy to Their Cuddle Plush

Introduce this toy to your dog when they are calm and relaxed, such as during bedtime. If you find your pet is chewing on or playing with the cuddle plush simply remove it for an hour or so, set it out of reach, and then re-introduce it to your pet again. The Frisco Cuddle Plush works best when placed in a crate with your new puppy during crate training.

Play Instructions

Please Read Through All Instructions Before Starting

1. Lay the toy flat on its belly facing away from you. There is a hook & loop opening on the side of the plush toy's body, look for the embroidered heart as an indicator. Open the hook & loop fasteners and insert the fully charged mechanism switched to your desired mode (see below).



2. Slide the toggle switch up for 30 minutes of use. After 30 minutes it can be reset by tapping on the mechanism. Toggle switch down to ON for continuous usage until battery is depleted. On a full charge this should last approximately 21.5 hours.

3. Ensure the hook and loop fasteners are securely closed. Then place the cuddle plush with your puppy while they are resting or in their crate.

Warning & Cautions

- Review all rechargeable lithium ion battery warnings & caution statements in this instruction manual prior to charging or operating device.
- DO NOT disassemble the battery compartment.
- DO NOT charge the device near any flammable substances.
- DO NOT operate this product while it is charging.
- The battery should be charged prior to use and only charged with the specified charger.
- Remove the heartbeat mechanism from the plush shell before charging.
- This product contains a non-replaceable lithium ion 300mAh battery. If the battery is exposed or removed, please dispose of the battery properly in accordance with your local waste rules and regulations.
- Ensure that both the product and battery are disposed of properly in accordance with your local waste rules and regulations.
- If you think the battery may have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Don't store the product with the battery in temperatures over 60°C/140°F.
- Keep out of reach of children.
- Should only be operated by responsible adult.
- Discontinue use if the toy is damaged.
- To extend the battery life, we recommend to charge the battery periodically even when the battery is not in use for an extended period of time.
- Use an adapter with 5V/1A output.

Care Instructions

Remove the heartbeat mechanism from the plush toy. Machine wash on gentle cycle. Air dry.

Battery Specifications

602030 Lithium Ion
Rechargeable Battery
5V 300mAh



Questions?

Call our friendly customer service anytime.

We're here 24/7 at 1.800.672.4399

frisco
by chewy

Call 1.800.672.4399 for questions