

GoGo Stik Instructions

TIP: The best and fastest way to grasp this concept is to watch our instructional videos. Go to your Browser or to Youtube and type in "**courtney gogostik**".

I. Out of the box

1. Hold the Head Assembly in one hand. Hold the handle in the other hand
2. Insert the threaded end of the handle into the neck of the Head Assembly.
REMEMBER: Righty Tightly & Lefty Lucy. That is, turn handle right (clockwise) to tighten & turn handle Left to Loosen.
3. Gently push in the handle about an inch and begin turning to the right to fix it in place. With about 3 to 4 half-turns, you'll feel it getting snug. Don't over-tighten.

II. Bag the GoGo Stik

TIP: Select the round blade edge for soft surfaces like grass, and the flat blade edge for hard surfaces like sidewalks.

TIP: There are various techniques you can try for different bag types. The best and fastest way to grasp this concept is to go to Youtube and type in "**courtney gogostik**".

Installing Dootie Bags (sample bags)

1. After placing bag over your hand, insert your hand through the head of the GoGo Stik, but keep the handles on either side.
2. Pull the front of the bag over the top shovel/blade. This will keep the tool clean when using!
3. For DOOTIE BAGS: Carefully pull back the handles and loop them over the closest hook (i.e. right loop over right hook). Push excess bag into top gripper.
4. For plastic grocery bags: Wrap the handles under and poke them into the Bottom Orange Gripper.

III. Scooping

TIP: Go to Youtube and type in "**courtney gogostik**" to see the GoGo Stik in action.

1. Stand to the side of your target and slightly ahead of it.
2. Place the blade behind the target and slightly under it.
3. While keeping the edge close to the ground, Drag or Sweep the blade under the target. Use a gentle twisting-of-the-wrist motion if needed.
4. Scoop through.

Be patient! Be creative! Have fun & practice!
You'll soon be an expert!



Pooch Approved Products, USA stands 100% behind our products.
For customer service, contact us at customercare@gogostik.com

Dexter, Customer Care Team

www.gogostik.com




GoGoStik



GoGoStik

GoGo Stik Parts Description



HDPE: High-density polyethylene is known for its large strength-to-density ratio. Strong, lightweight and flexible.

ABS: Acrylonitrile butadiene styrene has a high impact resistance and toughness, even in cold temperatures.



Pooch Approved Products, USA stands 100% behind our products. For customer service, contact us at customercare@gogostik.com

Dexter, Customer Care Team

www.gogostik.com



GoGoStik



GoGoStik

GRIPPER STEPS FOR REMOVAL AND INSTALLATION - DEMONSTRATION PHOTOS

USE THIS TECHNIQUE IF YOUR ORANGE GRIPPER SHOULD COME OUT OF ADJUSTMENT. PLEASE NOTE THAT THE ORANGE GRIPPER IS NOT GLUED. IT IS HELD IN PLACE BY FRICTION BETWEEN THE GRIPPER SHELF AND THE GOGO STIK HOUSING. USE THESE STEPS TO ACCESS THE GRIPPER TO RE-SEAT IT.



Night or Day! See & Be Seen! Check out our new FIDO, USB rechargeable LED light kit for your GoGo Stik!

- * Use Your GoGo Stik Night or Day, 365 days per year!
- * 2 LED, USB Rechargeable Flashlights. Use One While Charging the Other!
- * Custom Adapter holds flashlight and Easily Attaches Onto Your GoGo Stik.
- * Weatherproof!



Pooch Approved Products, USA stands 100% behind our products. For customer service, contact us at customer@gogostik.com

Dexter, Customer Care Team

www.gogostik.com

