


**For Models: DDC-2024, DDC-2030, DDC-2036, DDC-2042, DDC-2048
TDC-3024, TDC-3030, TDC-3036, TDC-3042, TDC-3048**



For safety, remove leash and collar before allowing pet to enter the crate.

Assembly Instructions (Drawings may vary from actual product)


Before assembling the crate, install Rubber Feet on the bottom wires first.




1. Remove the folded crate from the carton.
Unlatch the Locking Device located on the side.




2. Grab any wire on the top panel and turn it like the page of a book. Then grab the crate and pull it upwards.



3. Reach in the crate and pull the Door Panel forward until it fits into the hooks on the ends of the Side Panels.



4. To secure the Door Panel to the Top Panel, gently pull forward on the Door Panel while pushing down on the Top Panel, and then fit the hooks over the end wire on the top.



5. Repeat Step 3 and 4 with the end panel.

To disassemble, reverse this process.

Recommended for Crate Trained Pets

Although this is a well made product, no crate will contain a pet that chews or destroys it to get out. It is not recommended to leave an untrained pet in a crate.