



Dog Training Collar

User Manual

Models M86-1/M86-2/M86N



PLEASE READ THIS ENTIRE GUIDE BEFORE BEGINNING

PetSpy Advanced Dog Training Collar

Operating guide for models M86-1, M86-2 (2 dogs), M86N



PACKAGE:

- 1x Remote Transmitter
- 1x Receiver Collar (2 in M86-2)
- 1x Collar Strap (2 in M86-2)
- 2x Pair of Contacts (4 in M86-2)
- 2x Pair of Rubber Caps (4 in M86-2)
- 1x Dual USB Charger
- 1x Test Light

Frequency: 433.825Mhz
Transmitter: 3.7V 500mAh LiPo
Receiver: 3.7V 500mAh LiPo

Contact: support@petspy.com



**Contact Points
with Rubber Caps**

Testing Light Kit








Charger and USB Cable

Note: PetSpy has 3 models of Advanced Dog Training Collars: M86-1 (gray), M86N (black), and M86-2 (for 2 dogs). This manual is designed for all 3 models. Visit www.petspy.com to download this guide.

Dear Customer, thank you very much for choosing the PetSpy Brand! It's our pleasure to serve you and your beloved dog. Our mission is to ensure your pet's safety and happiness by providing you with the tools and techniques to successfully train your dog. If you have any questions, please contact PetSpy Customer Service at support@petspy.com - we will be happy to assist you!

FUNCTIONS, BUTTONS AND LCD ICONS

1. Charging Port
2. Transmitter Tone Button/Level Up
3. Vibration Button
4. Menu/Mode Button
5. Shock Button
6. Receiver Tone Button/Level Down

-  - Receiver Tone Level
-  - Shock Level
-  - Battery Charge Indicator
-  - Vibration Level
-  - Transmitter Tone Level
-  - Receiver A
-  - Receiver B



- Receiver Tone Level: indicates 3 Levels of Tone.
- Shock Level: indicates 8 Levels of Shock.
- Battery Charge Indicator: indicates 3 Levels of Battery Charge.
- Vibration Level: indicates 8 Levels of Vibration.
- A - Receiver A is being Controlled; B - Receiver B is being Controlled.
- A&B - both Receivers are being Controlled.

Menu/Mode Button - Press the button to change control between Receiver A, Receiver B, or Both Receivers A&B. Press and hold the button for 3 seconds to enter/exit Programming Mode. While in Programming Mode, press the button to confirm your selected settings (e.g. Shock or Vibration Level) and go to another one.

Shock Button - Press the button to deliver Shock Stimulation to your dog.

Vibration Button - Press the button to deliver Vibration Stimulation to your dog.

Receiver Tone Button/Level Down - Press the button to deliver Beeping Sound to your dog. In the Programming Mode, the button is used to lower the stimulation level (e.g. Shock).

Transmitter Tone Button/Level Up - Press the button to produce tone in the Transmitter. In the Programming Mode, the button is used to increase the stimulation level (e.g. Shock).

FEATURES

1. 3 Training Modes: Shock, Vibration, and Sound.
2. Rechargeable Transmitter and Receiver - recharge time is about 2-3 hours.
3. Fully waterproof Receiver Collar.
4. The system communication range is up to 1100 yards (in ideal conditions).
5. Eight correction levels of Shock and Vibration Stimulation.
6. The system can be used with 1 or 2 collars. It gives you a simultaneous control of up to 2 dogs.
7. Power Saving Design with auto sleep mode and remote collar activation.
8. Two pairs of metal contacts (short and long) for dogs with different hair length.
9. Two pairs of conductive rubber caps for added safety. They were specifically designed to avoid skin irritation and injuries.

HOW DOES PETSPY DOG TRAINING SYSTEM WORK?

PetSpy Dog Training System can assist you with controlling and training your dog without a leash in the range up to 1100 yards. Using a Remote Transmitter you can send a signal to the collar in form of Shock, Vibration, or Tone. By using PetSpy Dog Training System consistently, you can train your dog to eliminate any undesired behavior (jumping up, digging, chasing, etc.) and teach your dog understand many obedience commands (sit, come, stay, etc).

IMPORTANT NOTES

- The Remote System range goes up to 1100 yards. Hold the Transmitter horizontally and away from your body to achieve maximum range. Weather condition, terrain, vegetation, and interference from other electronic devices can affect the maximum communication distance of the system.
- There are 8 levels of Shock and Vibration Stimulation. If you use the strongest level there is a chance that it can penetrate dog's fur up to 6mm thick. Do not shave your Dog's neck to reduce the risk of skin irritation.
- For comfort, safety, and effectiveness of the system, please start training your pet with the lowest level of Shock. It's fine to have a Vibration level on medium or high. Please check your dog's neck after each training session for skin irritation. If skin irritation develops, discontinue to use the collar for 48 hours. If condition persist beyond 48 hours, please consult your veterinarian.
- Do not attach a leash to the collar. Use a separate collar if there is a need for a leash.
- We suggest you to use the Vibration Stimulation first before starting to use the Shock Stimulation. Then slowly start with the lowest level of the Shock Stimulation. If you follow this training method, your dog will learn that the Shock Stimulation will come after Vibration. Hence, the Vibration alone can effectively cure unwanted behavior of your dog without a need for the Shock.

PREPARING REMOTE TRANSMITTER FOR YOUR FIRST USE

- Please charge the Remote Transmitter for approximately 2 hours.
- The Charging Port is located on top of the transmitter (next to antenna).
- During the charge, the Battery Indicator icon will be flashing. When the battery is fully charged the indicator will turn solid, notifying you that the charging is completed.

REMOTE TRANSMITTER OPERATION

1. The remote always stays in the Stand-by Mode. Simply press any button to wake it up.
2. You can select which Receiver Collar is being controlled (A, B, or A&B) by pressing the Menu/Mode Button.
3. Press the Vibration Button to deliver the Vibration Stimulation to your dog.
4. Press the Shock Button to deliver the Shock Stimulation to your dog.
5. Press the Receiver Tone Button to deliver beeping noise to your dog during the Sound Training.

REMOTE TRANSMITTER PROGRAMMING

1. Press any button to make sure that Remote is on.
2. Press and Hold the Menu/Mode Button for 3 seconds until you hear a beep to enter the Programming Mode. The Receiver to be programmed (A, B, or A&B) will start flashing. If Receiver A is flashing, but you would like to program Receiver B or both Receivers A&B, simply use 2 Tone Buttons (upper left and upper right) to switch between the Receivers.
3. When desired Receiver is selected to be programmed (A, B, or A&B), press Menu/Mode Button to start setting it up. The setup process starts with the Receiver Tone Level. Use 2 Tone Buttons (upper left and upper right) to adjust its Level and then press Menu/Mode Button to confirm. Next, it will take you to the Vibration Intensity Level setup, Shock Intensity Level setup, and finally to the Transmitter Tone Level setup.
4. When programming is complete, press and hold Menu/Mode button to save your settings.
5. You can repeat Steps 2-4 to program Receiver A, Receiver B, or both Receivers A&B.

PREPARING RECEIVER COLLAR FOR YOUR FIRST USE:

Make sure that Receiver Collar is charged before proceeding to the training:

1. Carefully open the rubber cover over the charging port and connect the charger.
2. Red LED light will indicate that receiver is charging. It takes about 3 hours to fully charge it. Make sure to unplug the collar after 3 hours to avoid battery damage.
3. Put the rubber cover back over the charging port to ensure collar is fully waterproof.
4. Press the Power Button to turn it on. The red LED will start flashing every 4-5 seconds.
5. When Receiver is charged and turned on, it always stands in the Sleep/Standby Mode waiting for any command (e.g. Shock, Vibration or Beep) to activate it.

SYNCHRONIZING REMOTE TRANSMITTER WITH RECEIVER COLLAR

Sometimes the collar can loose connection with remote. The fix is pretty quick and simple. Follow these steps to re-synchronize the system:

1. Make sure that both the Transmitter and Receiver are fully charged and turned on.
2. Press and hold the Power button on the Receiver Collar for about 5 seconds to enter the Synchronization Mode - the receiver will beep and red LED will start flashing fast.
3. While red LED is flashing, send any correction command from remote. We recommend you to send a Vibration command by pressing and holding the Vibration button on remote until you feel that collar vibrating. If no command is sent, the flashing will stop after 10 seconds.
4. The system is now resynchronized - try to send any command to test it.

If you have 2 collars, repeat the above steps for both collars A and B. Make sure to set the Remote to mode A when synchronizing the first collar, and then switch it to B to synchronize the second collar.



Red LED Power Button

TESTING PETSPY DOG TRAINING SYSTEM

Shock Test:

- Take the included Test Light and put its metal wire on the Receiver's Contact Points.
- Press the Shock Button on the Remote Transmitter.
- The Test Light will light up indicating that shock is working.
- The higher the shock level is the brighter it should be.



Vibration Test:


- Press the Vibration Button on the Remote Transmitter.
- The Receiver Collar will vibrate indicating that vibration stimulation is working.
- Try to adjust the level of vibration and see how the intensity is changing.

Receiver Tone Test:

- Press the Receiver Tone Button on the Remote Transmitter.
- The Receiver Collar will beep indicating that receiver tone is working.

FITTING THE COLLAR

To ensure effective training and dog's safety, you must properly fit the collar on your dog. The collar must fit snugly to allow the "contact points" to have direct contact with the skin. Position the receiver unit high up on your dog's neck just below ears.



You should be able to fit two fingers between the collar strap and your dog's skin. Too tight poses the risk of skin irritation and discomfort. Too loose and the contact points will not be able to administer the stimulation reliably and can cause skin irritation due to chafing. Cover the contact points with conductive rubber caps to reduce the risk of skin irritation or injury.

CAUTION: E-collars are not designed to be worn constantly. We recommend using e-collars only under adult supervision and for no longer than 4 hours per day. NEVER attach a leash to an e-collar. Use a separate regular collar if there is a need for a leash.

Please refer to PetSpy Dog Training E-Book for more dog training tips.

You can download it at www.petspy.com - it is free!

GENERAL TIPS

- PetSpy Dog Training Collar is not design to be worn constantly. We recommend you to limit collar usage just for active Training Sessions. Always take off the collar when you leave your dog unattended.
- Most dogs will feel uncomfortable when wearing collar for the first time. Don't use any commands until your dog has gotten used to the collar which will normally take several days.
- Eliminate one unwanted action or teach one obedience command at a time. If you move to quickly with training, your dog may become confused.
- Be consistent in your training. Give your dog the same stimulation for each unwanted action. We suggest you to use Vibration Stimulation before starting the Shock Stimulation. If you follow this training method, your dog will learn that Shock Stimulation might come after Vibration. Hence, the Vibration Stimulation alone can effectively cure unwanted behavior of your dog.
- Do not over-correct. Use as few stimulation as possible to train your dog.
- Following a predefined scenario in all Training Sessions can dramatically improve your chances of success.
- Should your dog react to the training by hiding or reacting fearfully, redirect his attention to a simple command such as "Speak" or "Sit" to calm him down. Use treats to help your dog understand which commands have been done correctly.

TROUBLESHOOTING

My e-collar does not respond to any command, what should i do?

- Make sure that both the Remote Transmitter and Receiver Collar are fully charged and turned on. The red LED on the receiver should be flashing every 4-5 seconds.
- Follow the steps from "*Synchronizing Remote Transmitter with Receiver Collar*" paragraph to pair remote transmitter with the collar.
- Watch our video guides for more information at www.petspy.com
- Contact us at support@petspy.com if the above steps don't help.

REGULAR MAINTENANCE AND STORAGE

- When not used, PetSpy Dog Training System must be kept in a dry place just like any other electronic devices.
- To prevent batteries from damage, charge both the Transmitter and Receiver regularly even when it's not used. Make sure you do not charge it for longer than 3 hours.
- Clean the receiver and contact points weekly. Make sure that contact points are tightly attached to the collar.
- Check your dog's neck for irritation daily.

FREQUENTLY ASKED QUESTIONS

1. Is the Receiver Collar waterproof?

Yes, the Receiver Collar is fully waterproof.

2. Is the Remote Transmitter waterproof?

No, the Remote Transmitter must be kept away from water.

3. Once my dog is trained, do we have to continue using the collar?

You might have to reinforce training with the collar from time to time.

4. How long can I continuously deliver Vibration or Shock to my dog?

The max amount of time you can deliver the Vibration or Shock to your dog continuously is 10 seconds. The remote transmitter will time out and the Vibration/Shock button must be released and pressed again.

CAUTION: While it is fine to use the Vibration for up to 10 seconds, it is highly recommended to limit the continuous Shock delivery to no more than 3 seconds (the smaller the dog the shorter it should be).

5. What should I do if my dog's neck becomes red and irritated?

Stop using the collar immediately for at least 48 hours. If the condition persists beyond 48 hour please consult your veterinarian.

6. Can I attach a leash to the Receiver collar?

No, this can result in pulling the contact points to tightly against your dog's neck causing an injury. Use a separate collar when needed.

7. How long can I leave a Receiver Collar on my dog?

E-collars are not designed to be worn constantly! We recommend to use it only during active training sessions and outdoor activities for no longer than 4 hours per day under adult supervision.

8. How long should the training sessions be?

Training sessions should be kept short and positive (10-15 minutes).

9. How long does the battery charge last?

It depends on the intensity of training sessions and vary from one day to one week.

10. What is the maximum operational range?

The max operational range is 1100 yards in ideal conditions. The range may vary depending on the terrain, buildings, trees and electromagnetic interference.

11. Will the collar fit my dog?

The collar strap is adjustable to fit dogs from 10 to 140 pounds. It has a maximum length of 26 inches and minimum length of 8.

12. What is the best dog's age to start training?

Your pup should be old enough to understand basic commands. 6 months is normally a good age.

Should you have more questions, feel free to contact us at support@petspy.com

Dog Breeds by Average Size and Weight				
Size	Neck (cm)	Chest (cm)	Weight (LB)	Type
Mini	20-22	25-30	9	Chihuahua, Yorkshire Terrier, Pekingese
Small	20-24	29-36	9-15	Chihuahua, Yorkshire Terrier, Pomeranian
Medium	23-28	35-42	15-35	Cocker Spaniel, Shih Tzu, Beagle, Poodle
Large	27-31	41-47	35-55	Boxer, Golden Retriever
Large	30-34	46-53	35-55	Schnauzer, Labrador Retriever
Large	33-37	52-59	35-55	Bull Terrier, Basset Hound
Huge	43-48	76-84	55-120	German Shepherd, Husky
Huge	47-52	88-97	55-120	Rottweiler, Pitbull
Huge	52-62	92-100	55-120	Great Dane, Old English Sheepdog

With PetSpy Advanced M86-2 Dog Training System you can train up to 2 dogs at the same time using one Remote Transmitter. This is how it looks like on the LCD screen:



Training Dog A



Training Dog B



Training 2 Dogs A&B
at the same time

TERMS OF USE AND LIMITATION OF LIABILITY

1. Terms of Use

This Product is designed to be used with dogs where training is desired. The specific temperament of your dog may not work with the product. We do not recommend you to use this product if your dog is less than 10 lbs, under 6 months old, or if your pet is aggressive. If you are unsure whether this is appropriate for your pet, please consult your veterinarian, or a certified trainer. Proper use includes reviewing the entire User Manual and Dog Training Guide provided with the product. Pay extra attention to all Caution statements.

2. No Unlawful or Prohibited Use

This Product is designed for use with dogs only. PetSpy dog training collar is not intended to harm, injure, or provoke. Using this product in a way that is not intended could result in violation of Federal, State or local laws.

3. Limitation of Liability

In no event shall we be liable for any direct, indirect, punitive, incidental, special or consequential damages and injuries, or any damages and injuries whatsoever arising out of or connected with the use or misuse of this Product. Buyer assumes all risks and liability from the use of this Product.

4. Modification of Terms and Conditions

We reserve the right to change the terms, conditions and notices under which this Product is offered.

WARRANTY

Please register your 1-year replacement warranty at www.petspy.com. If your purchased e-collar malfunctions or breaks within 1 year, we will send you a free replacement. No more than one replacement per purchased item. Replacement warranty does not apply to promotional orders with total discount greater than 30%. The warranty begins from the date of purchase. A purchase confirmation such as amazon order id is required for a claim. The warranty does not cover products with physical damage or lost items. PetSpy does not offer warranty for products purchased from unauthorized resellers such as online auctions. PetSpy products are exclusively sold on Amazon.com, Chewy.com, Walmart.com and PetSpy.com. Any other sources are considered as unauthorized resellers. The refund period is strictly limited to 30 days for all products starting from the date of purchase.

support@petspy.com

Copyright © 2015-2019 PetSpy Inc. All rights reserved.

