# **Thermo-Poultry Brooder**

Care & Instructions



Thank you for purchasing a Thermo-Poultry Brooder by K&H Pet Products. When cared for properly, your brooder will provide years of hassle-free service. Features include a convenient "tilt" option, only 25 watts, a 5'6" power cord, simple to adjust heater height, and tool-free assembly! MET Listed

**WARNING:** This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electrical shock or fire which could cause serious bodily injury.


## **IMPORTANT FEATURES:**

The K&H Thermo-Poultry Brooder's easy adjustable height, coupled with the special "tilt" option make it the most chick-friendly brooder on the market.

For instances of small chicks, utilize the tilt option so the front of the heater is taller and leans toward the back. The baby chicks will use the option of staying toward the front or back depending on the level of warmth desired.


## **INSTRUCTIONS:**

Run the cord through the center hole in one of the end braces. **See Figure 1**.



Choose the holes for the correct height of the heater panel. Line up the connectors on the heater panel with the holes on the end braces. **See figure 2**.

Push firmly to seat the heater panel connectors into the end braces. It's that simple!



#### NOTE:

As your chicks grow, you can easily adjust the height of the heater panel by choosing the next set of adjustment holes.

#### IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- To protect against electrical hazards, **DO NOT** immerse cord, plug, or appliance in water or other liquid.
- Close supervision is necessary when used by or near children.
- **ALWAYS** unplug from outlet when not in use.
- **DO NOT** operate any electrical appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any way. **RETURN** all malfunctioning appliances to the factory for examination.
- **DO NOT** use appliance for anything other than its intended use.
- DO NOT PUNCTURE HOUSING FOR ANY REASON.
- For use with 110-120 volt AC **ONLY.**
- Always make sure the cord exits your chick's enclosure. Keep cord out of shelter.

## Cleaning:

Your THERMO-POULTRY BROODER may be wiped down with a soap solution and a damp cloth. Thoroughly dry before using.

#### **K&H Limited Two Year Warranty**

**Our warranty is as follows:** K&H Pet Products warrants to the original consumer, that this product will be free of defects and workmanship for a period of two years from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is woid if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material and workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your original purchase receipt. If this cannot be done, return the product, postage prepaid, to K&H Pet Products, with a dated proof of purchase or original date receipt. A return authorization number can be obtained by calling (719) 591-6950 and must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.