

# Wall Sisal Cat Scratcher Product Manual

### SKU# 214352, 214353

19.29 IN L X 9.44 IN W 49 CM L X 24 CM W SKU# 214354, 214355 27.16 IN L X 11 IN W 69 CM L X 28 CM W



Please read through all instructions before starting.

# **Parts Included**

Prior to assembly, please be sure to identify and sort all parts shown below.



# Accessories



$\Rightarrow$	
	С



4 Drywall Anchors 30 mm

4 Hook-And-Loops (Already Attached To The Board)





#### **Option 1 - Screw Mounting**



Place the scratching board on the desired wall location and mark screw holes using the plastic as a guide. Pre-drill holes at marks, insert wall anchors (C). Secure plastic tabs on the scratching board to the wall with the 4 screws (B) and washers (A) provided using a Phillips head screwdriver.

#### **Option 2 - Hook & Loop Mounting**



Peel the paper backing from the hook side of the hook-and-loop strips (D). Place the scratcher on the desired wall location and press firmly.

# Warning & Cautions

Please read and follow all warnings and instructions to avoid injury or property damage.

This is not a toy, not for use with children.

Keep all small parts away from children / pets to avoid choking hazards.

For cat use only.

Should only be operated by a responsible adult.

Keep all tools and instructions in a safe place for future reference.

Follow the instructions carefully and make sure you've completed each step.

Cat tree should be placed on a flat level surface.

Never climb, rock, shake, step or hang on the cat tree.

Check your cat tree often for loose screws or parts that might need re-tightening.

If your cat tree gets torn or damaged, please discard it.

The product photo may vary slightly from your fully assembled cat tree as this product is continually being enhanced.

### Cleaning & Instructions

Spot clean stains and vacuum fur (using small handheld or attachment) when necessary.

## **Questions?**

Call our friendly customer service anytime. We're here 24/7 at 1.800.672.4399

