



Hygena Claw Scooper with Bag Holders ASSEMBLY INSTRUCTIONS Buy more waste bags on our Hygena Scoop® e-store


How to unfold and lock scooper:




STEP 1 Hold the Scooper



STEP 2 Unfold & Straighten the Scooper



STEP 3
Slide the Lock into Position




STEP 4 Finished Installation


How to install waste bags:




Step 1.
Place hand inside waste bag




Step 2.
Open claw and insert bag into center bag lock



Close claw and pull bag down towards side bag locks



Insert excess bag into both side bag locks



<u>Step 5.</u> (Waste disposal)
Pull bag out of side bag locks then
open claw and remove bag for disposal

Warnings:

Pet use only. Not a toy; to avoid danger of suffocation, keep the plastic bags away from babies and children. Never leave scooper or bags unattended with children. The scooper and bags are not a toy. Do not use the bags in cribs, beds, carriage, playpens, or anywhere other than for pet waste disposal.

How are we doing?

To Submit a Product Review: Go to the product detail page for **Hygena Scoop.** Click **Write** a customer **reviews** n the customer **reviews** section. Click **Submit.**