



29.5-in Holiday Sisal Cat Scratching Post with Toy Product Manual

SKU# 236565


**15.75 IN L X 15.75 IN W X 29.5 IN H
40 CM L X 40 CM W X 75 CM H**

Assembly Instructions

Please read through all instructions before starting.

Parts Included

Prior to assembly, please be sure to identify and sort all parts shown below.
No additional tools required.



1 Baseboard




1 Scratching Post
15.75 inch



1 Scratching Post
7.87 inch



1 Star




Accessories




A

1 Bolt
10 mm x 40 mm



B

1 Double-Sided Bolt
M10 mm x 85 mm



C

1 Washer
10 mm x 30 mm



D

1
5 mm Allen Wrench




NO

YES


Assembly Instructions

Please Read Through All Instructions Before Starting


Step 1.



Step 2.



FINISHED ASSEMBLY



Warning & Cautions

Please read and follow all warnings and instructions to avoid injury or property damage.

This is not a toy, not for use with children.

Keep all small parts away from children / pets to avoid choking hazards.

For cat use only.

Should only be operated by a responsible adult.

Keep all tools and instructions in a safe place for future reference.

Follow the instructions carefully and make sure you've completed each step.

Cat tree should be placed on a flat level surface.

Never climb, rock, shake, step or hang on the cat tree.

Check your cat tree often for loose screws or parts that might need re-tightening.

If your cat tree gets torn or damaged, please discard it.

The product photo may vary slightly from your fully assembled cat tree as this product is continually being enhanced.

Cleaning & Instructions

Spot clean stains and vacuum fur (using small handheld or attachment) when necessary.

Questions?

**Call our friendly customer service anytime.
We're here 24/7 at 1.800.672.4399**