

# **B3V8 COLLAR BATTERY**



***FOR USE WITH:***  
***RC-8 ELECTRONIC FENCE COLLAR***  
***&***  
***BT-3 BARK TERMINATOR***

***OPERATING INSTRUCTIONS***

**RC-8**



**BT-3**



## **INSTALLING & REPLACING THE BATTERY PACK**

The replaceable battery pack installs at the bottom of the unit, between the STIMULUS PROBES. Note that there is a small tongue on the battery pack that lines up with a groove in the collar casing. This is to ensure that the battery pack is installed correctly. Line up the tongue with the groove and push firmly. You will hear two clicks as the battery pack snaps into place.



To remove the battery pack, squeeze together the two finger tabs on each side of the battery pack and pull it out of the casing.

## Battery Life

The battery life of your RC-8 collar depends upon how often your pet strays into the boundary field. It will operate for several weeks in the absence of any required shock output. If your pet is receiving corrections very often, it may be necessary to replace the battery after only one or two weeks. In addition, you should expect to use at least one battery during the initial training.



*High Tech Pet Products, Inc.*

*2111 Portola Rd., Suite A Ventura, CA 93003*

*[www.hightechpet.com](http://www.hightechpet.com)*

