


Cozy//p" STEPS & RAMP COMBO


1




To unfold, pull back on the leg until it locks into place. The steps & ramp combo is 20 inches high with the leg fully extended.

Because your home should fit your pet.






To lower to 16 inches, release the latch and fold under the lower portion of the leg. When you want to raise it back up to 20 inches, just unfold the leg and refasten the latch.




To use as steps, lift the top tread and find the hinged step riser underneath it. Raise the step riser and insert it into one of the two slots on the underside of the tread. Make sure the step is level; if not, move the step riser to the other slot on the underside of the tread.

Set up the middle step and then the bottom step in the same manner. Always work from top to bottom when setting up the steps.



To convert back to a ramp, lift each tread and fold the hinged step riser beneath it.



To fold for storage, press up on the hinged panel above the leg and fold the leg under the steps. (Be careful not to pinch your fingers.)



Offer treats to gently encourage your pet to practice walking up and down. Don't worry if your pet hesitates at first. We all need a little reassurance sometimes! With a little patience and lots of praise, your pet will soon be happy using the steps or ramp on his own.

Now your best friend can join you wherever you choose.

Let us help!

For questions or additional tips: +1 (800) 732-2677 petsafe.com

1-Year Warranty
@2020 Radio Systems Corporation
Model: PTV00-17052 | Z400-2493
For important safety information, please see the customer care quide.

live happy together.