

展开尺寸：75*160mm 折后尺寸：75*80mm

正面

反面

Simple Quick Start Guide

Step 1

Select the metal probes to use based on your dog's fur length



Step 2

Charge product before using
Use 5V/1A power adapter



Step 3

Turn the product on

Press the power button  for 2 seconds until the green light is on.



Step 4

Manual Test - Refer to the 7 correction levels explained in the operating instruction for results



Step 5

Adjust Sensitivity levels

Press  button to adjust sensitivity level from 1-7.

The 4th level is set automatically after the device is turned on.

Adjust Sound/Shock Levels

Press  or  button until the icon flash, then press  button to adjust the sound/shock levels.



Step 6


Fit the collar on your dog

Adjust the strap to the size of your dog's neck.
Make sure the product is on the center of the neck, and ensure that no more than one finger can pass through.
The collar will automatically begin its job.



OPERATING INSTRUCTIONS

Anti bark collar has 7 correction levels, which deliver sound, vibration or shock function.



Under Sound Mode:

- 1st blow: 1.5s beep
- 2nd blow: 2.5s beep
- 3rd blow - 7th blow: 5s beep
- 8th blow: Sleep Mode for Safety (for 75 seconds)

Under Vibration/Shock Mode:

- 1st blow : 1.5s beep;
- 2nd blow : 2.5s beep;
- 3rd blow : 5s beep, then 1s vibration/shock;
- 4th blow : 5s beep, then 1.5s vibration/shock;
- 5th blow : 5s beep, then 2s vibration/shock;
- 6th blow : 5s beep, then 3s vibration/shock;
- 7th blow : 5s beep, then 4s vibration/shock;
- 8th blow : Sleep Mode for Safety (for 75 seconds)

Each bark should be within 40 seconds.

If the barks interval time exceeds 40 seconds, the device will revert to correction level 1.