



Step 2 Fully insert tabs into Panel (A), then wrap the tabs around and insert into the small slots as detailed below.




8.5" x 11" (21.6cm x 27.9cm) Instruction Sheet - FRONT

Step 3


Fold **Platform (C)**, and while holding tight, insert into slots in **Completed Panels** as shown. Fully insert into one side before inserting into the other.








Step 5 Assemble Panel (A) to Completed Panels as pictured below. Fully insert tabs into Panel (A), then wrap the tabs around and insert into the small slots as detailed below.




Step 6 Place Combined Panels over Scratcher (D).

Step 7 Fold bottom flaps of **Panels (A)** under **Scratcher (D)**. Fold front and back tabs up, and insert into the slots of **Completed Panels** as pictured below.



Step 8 Insert Wings (E) as pictured below.



Because every cat is different, it is important to monitor your cat's behavior with this product. If at any time your cat damages this item, or any portion of this item becomes damaged, remove the damaged portion or discontinue use of the product.

QUESTIONS?

Call our friendly customer service team any time. We're here 24/7! 1-800-67-CHEWY (672-4399)