

210x260mm

Interactive Scratcher Step by Step

frisco[®]
by chewy

WARNINGS & CAUTIONS

PLEASE READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS TO AVOID PET INJURY OR PROPERTY DAMAGE.


- Follow the instructions carefully and make sure you've completed each step.
- Not suitable for children, please keep children away.
- This cat scratcher is intended for cat use only, not for use with other pets/animals.
- Keep all small parts away from children/pets to avoid choking hazards.
- Never climb, rock, shake, step or hang on the cat scratcher.
- Cat scratcher is for indoor use only.
- Cat scratcher should be placed on a level surface for stability.
- Check your cat scratcher often for loose screws or parts that might need re-tightening.
- If your cat scratcher gets torn or damaged, please discard it.
- The product images shown in this manual may vary slightly from your fully assembled cat scratcher as this product has multiple designs.

COMPONENTS

Prior to assembly, be sure to identify and sort all components shown below.



Post Cap




Curved Poles



Screw




Sisal Post




Cardboard Base
(with included balls)

ASSEMBLY INSTRUCTIONS


Step 1: Locate the included screw and twist it into the cardboard base until you begin to feel slight friction. Then, attach the sisal post to the screw and twist until secure. Be careful not to overtighten the sisal post.




Step 2: Screw the post cap onto the top of the sisal post. Then attach the two curved poles with dangling toys onto the post cap as shown. Make sure the poles are curved up and over, so that they spin around the cardboard base.



Tip: Make sure the curved poles are assembled as pictured below, so that they spin around the cardboard base.



Final Touches: Add a sprinkling of catnip and your cat is ready to play!



QUESTIONS? Call our friendly customer service team anytime. We're here 24/7! 1-800-67-CHEWY (672-4399)