


Dog & Cat Collapsible Stroller, Black

360995

frisco
by chewy

Components


Cup Holder (1)




Front Wheel (1)



Back Wheel Set (1)



Frame With Fabric (1)
(Including pad and cargo basket)




Assembly

DO NOT SKIP THIS STEP

Lay the parts out flat on the ground so that you have a clear visual of everything that is included.

Step 1 - Unfold

Unfold your pet stroller until the pieces lock into place. Make sure the locks on the sides completely snap closed.



Step 2 - Front Wheels


Turn your stroller upside down, then insert the front wheel into the single wheel pole until it snaps into place.

Pro tip: give it a good tug to make sure it's secured.

Step 3 - Back Wheels

With the locking breaks facing the back of the stroller, attach the back wheel bar onto the two wheel poles until it snaps into place.

Lock the rear wheels by simply pushing down the brake levers on either side.



Step 4 - Carrier Assembly

- A) Turn your stroller right side up, then push the metal bar frame down so that it is horizontal.
- B) Slide the fabric basket sides over the metal bar and snap them into place. Fabric should fit snugly over the bar.



Step 5 - Bottom Basket Assembly

- A) Use the hook-and-loop fasteners to attach the sides of bottom basket to frame.
- B) Fold back of basket over the frame and snap into place.



Attachments

Cup Holder

Attach the cup holder to the desired location on the handle by clipping it into place on the stroller frame.



WARNING

- Not intended for children.
- NEVER leave pet unattended. ALWAYS keep pet in view while in the stroller.
- Adult assembly required. Take care when unpacking and assembling; contains small parts and some items with sharp edges.
- To prevent a possible choking hazard, remove and discard packing material before using this product.
- DO NOT carry or roll stroller on stairs or escalators with pet inside.
- DO NOT hang heavy items on handle bar as this can cause the stroller to tip.
- Be sure stroller is fully assembled and locked in unfolded position before using.
- ALWAYS exercise care when going over curbs or steps, and never use stroller for anything other than transporting your pet.
- Push stroller at a normal walking pace only; faster strolling can cause a loss of control and injury to the pet.
- DO NOT place hot liquids in cup holder.
- DO NOT use stroller if any parts are missing or broken.
- DO NOT carry additional pets, goods, or accessories in or on this stroller except as advised in these instructions.
- DO NOT exceed the listed weight restriction.
- Care must be taken when folding or unfolding stroller to prevent finger injury to you or your pet in hinge areas.

- Make sure pet is not in the seat or near the stroller when folding or unfolding.
- NEVER leave stroller on a hill or incline, even with brakes set. Stroller may tip, injuring the pet.
- To avoid accidental rolling, ALWAYS set brakes when stroller is not being pushed.
- DO NOT suspend strings or toys from the canopy to avoid strangulation.
- When making adjustments to the stroller, ALWAYS ensure that all parts of the pet's body are clear of any moving parts of the stroller.

To fold the stroller:

1. Pull up both side locks
2. Fold the pet stroller
3. Secure the side safety lock