



For The ON-THE-GO Pet™

INSTRUCTION MANUAL

TRAVEL LITE SOFT-SIDED PET PEN

TL4129/TL4136/TL4146



To see our full line of products, visit us online at: www.petgearinc.com

CUSTOMER SERVICE HELP DESK

customerservice@petgearinc.com

Toll-Free 877-752-9123 - Eastern Standard Time 8am-3pm, Monday through Friday

PARTS LIST

Check that you have all the parts shown BEFORE assembling your product.
If any parts are missing, call Customer Service.



Soft-Sided Pet Pen

SET UP

Unpack pet pen, then pull on elastic straps to open.

Pet pen, below, is shown open, after the elastic straps are released.



OPENING THE PEN

Step 1. Unfold pen, and pull outward, and push sides into shape. The sides snap right into place.



Shown closed and flat.

Step 2. Open pen, and pull sides out and apart.



Step 3. Push sides outward until they snap into place.



Pen shown opened with several sides snapped into place.



Shown open with all sides in place.

FOLDING THE PEN FOR TRAVEL OR STORAGE

Shown open with top.



Step 1. Unzip the top.



Prior to folding, make sure that the side with the elastic strap gets folded last.



Step 2. Fold sides inward.



Step 3. Make the shape of a "W" to make folding easier.



The pen shown closed, and flat with the elastic strap secured around it.



CARE AND MAINTENANCE

From time to time, check your pet play area for worn parts, torn material or stitching.
To clean pet play area, use only household soap or detergent and warm water.

AVOIDING SUFFOCATION HAZARDS

Never use plastic shipping bags or other plastic film as pad covers not sold and intended for that purpose.
They can cause suffocation. This product is not intended for commercial use.

SETTING UP THE PET PLAY AREA

THIS PRODUCT REQUIRES ADULT ASSEMBLY.

Be sure the pet pen is completely set up before use.

Always follow the instructions in the product instructions to set up the pet pen.

Before each use, inspect this product for damaged hardware, loose joints, missing parts, or sharp edges.

Do not use the pet pen if any parts are missing or broken.

Call **PET GEAR** at 1-877-752-9123 for replacement parts. Use only **PET GEAR** replacement parts.

Visit our website www.petgearinc.com to view or download the product instructions.

Do not substitute parts.

USING THE PET PLAY AREA

Remove collar and leashes while using this product. The pet pen is for playing or sleeping.

When used for playing, never leave pet unattended and always keep pet in view. When used for sleeping, you must still provide the supervision necessary for the continued safety of your pet.

Always keep the pet pen away from hazards in the area that may injure your pet.

DO NOT leave pet in product for prolonged periods of time.

WARNING!

FOR PETS ONLY.

Not intended to be used as a restraining device for aggressive or dangerous animals that dig, chew or paw aggressively. Do not leave your pet unattended. **PET GEAR** is not liable for any damage caused by aggressive, destructive, immature or untrained animals. Do not use near an open or exposed flame. Failure to follow these warnings and the instructions could result in serious injury or death.

REPLACEMENT PARTS

Use only **PET GEAR** replacement parts.

Please have your model number ready before calling.

You can also request parts: <http://www.petgearinc.com/main.asp?sel=2>



192 Sheldon Avenue • West Rutland, VT 05777 • 877-752-9123 • www.petgearinc.com