


Ghost Scratch House


This Package Contains

23C-SR089

1/18/24 V2




Completed Item




Step 1

Fold **Platform (D)**, and while holding tight, insert into slots on top of **Panels (A)** and **(B)** as shown.





Step 2

Fully insert indicated tabs of **Panel (C)** through the large slots in **Panels (A)** and **(B)** as shown below. Make sure the side of **Panel (C)** indicated "**FRONT**" and the side of **Panel (C)** indicated "**BACK**" match the illustration below.




Step 3


Fully insert remaining tabs into **Panels (A)** and **(B)** as shown below. Wrap the tabs around and insert into the small slots as detailed below. Repeat on the back side.




Line up tab with large outer slot.



Push completely through.





Fold front and insert tab into small slot.



Step 4

Place completed panels over **Scratcher (E)**. Fold bottom flaps of **Panels (A)** and **(B)** under **Scratcher (E)**. Fold front and back tabs up, and insert into the slots of **Completed Panels** as pictured below.



Because every cat is different, it is important to monitor your cat's behavior with this product. If at any time your cat damages this item, or any portion of this item becomes damaged, remove the damaged portion or discontinue use of the product.

QUESTIONS?

Call our friendly customer service team any time. We're here 24/7! 1-800-67-CHEWY (672-4399)