

For The ON-THE-GO Pet™

INSTRUCTION MANUAL SPORT LITE PET STROLLER

PG80300B/PG8030PK



To see our full line of products, visit us online at: www.petgearinc.com

CUSTOMER SERVICE HELP DESK


customerservice@petgearinc.com

Toll-Free 877-752-9123 - Eastern Standard Time 8am-3pm, Monday through Friday

PARTS LIST

Check that you have all the parts shown BEFORE assembling your product.


If any parts are missing, call Customer Service.



OPENING THE STROLLER

Step 1. Release locking latch

Step 2. Unfold as shown. Make sure both locks snap into place.






TO ASSEMBLE FRONT WHEELS

Step 1. Turn stroller over as shown.


Step 2. Push wheel assembly onto stroller leg until it snaps into place.

Step 3. Repeat for other wheel.

Tug firmly on each wheel assembly to be sure wheels are securely in place.



Note Direction of Arrow





TO ASSEMBLE REAR WHEELS

Step 1. Remove and discard protective sleeve from ends of rear axle assembly and rear leg tubes.

Step 2. Position rear axle assembly onto rear leg tubes at the same time.



TO ASSEMBLE REAR WHEELS

Step 3. Slide wheel onto axle.

Step 4. Slide washer onto axle.

Step 5. Fit straight part of cotter pin through hole on axle.

Step 6. Line up each of the tabs in the hub cap with the slots in the wheel.

Snap hub cap into place.

Fit cover to collet by firmly pressing the cover into place.

Step 7. Repeat for other side.










APPLYING THE BRAKES

Step 1. Push levers on both rear wheels down to lock.

Step 2. Pull levers up to unlock.


WARNING: Never leave your stroller parked without applying brakes.



FOLDING THE STROLLER



Step 1. Before folding the stroller, lock the brakes and close the canopy.





Step 3. Fold as shown.

Step 4. Engage locking latch.



NOTE: Fold stroller so wheels straddle frame.



DO NOT allow wheels to press against frame as this may damage tires.

LOOKING AFTER YOUR STROLLER

- Always store product in a clean, dry place.
- · Not recommended for use on the beach.
- Do not put heavy items on top of the stroller.
- Clean frame by wiping with a lightly oiled cloth.
- Do not use detergent or abrasives. Spot clean fabric with dry cleaning fluid or mild soap and warm water.
- To ensure easy maneuverability and to minimize wear and tear, (especially wheels, axles, and swivels), keep all moving parts clean and lubricated with WD40[®] or light machine oil.
- NOTE: Do not lubricate brake components or swivel locks.
- Regularly check stroller for loose parts. These should be tightened or replaced.

WHEEL MAINTENANCE

- To clean and lubricate front and rear wheels, push out locking lever under wheel housing to release rear wheel.
- To ensure ease of maneuverability and to minimize wear and tear, keep all moving parts clean and lubricated with WD40® or light machine oil.
- Push wheel sets back on until they click and lock in position; pull on wheel housings to ensure they are secure.
- Push stroller back and forth and rotate swivels around to work in lubricant.
- Clean the rear wheel assembly and the rest of the frame with warm, soapy water; clean off with warm water and dry thoroughly.
- NOTE: Do not lubricate brake components or swivel locks.

△ WARNING!

FOR PETS ONLY.

Not intended to be used as a restraining device for aggressive or dangerous animals that dig, chew or paw aggressively. Do not leave your pet unattended. **PET GEAR** is not liable for any damage caused by aggressive, destructive, immature or untrained animals. Do not use near an open or exposed flame. Failure to follow these warnings and the instructions could result in serious injury or death.

- Do not carry additional bags, goods, or accessories in or on stroller except as recommended in the manufacturer's instructions.
- Recommended use of an approved safety restraint correctly fitted and adjusted.
- Do not leave pet unsupervised in stroller.
- Before making adjustments to stroller ensure that pet's body is clear of any moving parts.
- This stroller is designed for one pet only.
- Do not hang bags from handles as this may cause the product to become unstable.
- Do not use on escalator or stairs; fold stroller and carry.
- Put on brake whenever you park the stroller.
- Ensure stroller is completely erected and check that all locks are engaged before placing pet in stroller.
- Do not overload as stroller may become unstable; maximum weight of pet using this stroller not to exceed 20 lbs.
- Any goods carried in the basket not to exceed 6 lbs.

REPLACEMENT PARTS

Use only **PET GEAR** replacement parts.

Please have your model number ready before calling.

You can also request parts: http://www.petgearinc.com/main.asp?sel=2



192 Sheldon Avenue • West Rutland, VT 05777 • 877-752-9123 • www.petgearinc.com