TC-001/TC-002B

Product name : Bark Training Collar
Product model : TC-001/TC-002B
Operating voltage : 3.7V
Battery capacity : 300mAh
Rated input : DC 5V / 1A
Waterproof rating : IP67
Operating temperature: -10°C~+50°C
Storage temperature: -20°C~+60°C
Device volume : 70mm*37mm*40mm
Net weight : 90g

Made in China

User Operation

Power ON & OFF

Long press to turn ON — With:

Long press to turn OFF — With:

* Must enter setting mode for turn OFF. See Page 9 for instructions to enter setting mode.

View Function settings

Short press to View Mood — Toggle through and view settings and battery level.

View Loop:

- E-Shock setting, 7 is highest shock, 0 is off
- Vibration setting, 7 is highest vibration, 0 is off
- Bark sensor 7 is most sensitive
- Battery indicator

User Operation

Functions Setting Process

- Short press to wake up device — View mode
- Tap 3 times to enter setting mode — Display Function icons with beep
- Tap to switch functions — Loop display with beep
- Tap to adjust level — Loop display with beep
- Automatically exit setting mode after 3 secs — Stop Touching! — Settings are set. Display goes away.
- Long press to turn OFF — With:

* The default setting is: sensitivity sensor level 6, vibration level 3, E-Shock level 0.

User Operation

General Setting Guidelines

Sensitivity Setting — Theoretically, the louder the barking sound, the lower the sensitivity level.

Triggered

Beep Setting — No setting required. For well-trained dogs.

Vibration Setting — Low discomfort warning. Suitable for most dogs.

E-Shock Setting — High discomfort warning, more suitable for large dogs, high endurance dogs. Small dogs can be gradually strengthened from a low level.

More Barking / Less Barking — Training Method

User Operation

Other Setting Considerations

Every pet is unique. Please set more suitable function parameters according to your pet's own characteristics, living environment, and other factors.The following points are general recommendations and are for reference only.

- Well-Trained — Use only beep or use low-level settings.
- Body Size — Small dogs gradually increase from a low-level.
- Tolerance — Dogs with high endurance need higher setting levels.
- Many Together — Reduce the sensitivity level to fit just one dog.
- Ambient Noise — Reduce the sensitivity level to avoid false triggering.
- Dog Mood — When pets feel uneasy and depressed, please keep only beep or low level stimulation.

User Operation

General Advice

Not Sensitive / (Dogs) / Sensitive — Small Size / Large Size

Battery Indicator

Low Battery — Battery level — Full Battery — Charging Light

Battery Charging

View Battery Indicator — At 2 level battery indicator, please charging in time.

User Operation

Automatic Shutdown Prompt

Run Out of Battery — Flashing 30 Times — Automatically shuts down, after prompt flashes

Other Precautions for Use

- Please remove the product before playing with the dog. Dog barking during play can cause unnecessary triggers.
- Please shut down when not in use, and keep the product in a safe place out of reach of children and pets.
- It is recommended to clean the product weekly with alcohol or other disinfectants, especially the contacts. Please shut down when cleaning.
- Remove all other types of collars. These collars will produce noise that will cause false triggers.
- It is forbidden to use this product as a matching collar for pet leashes.

User Operation

Troubleshooting

If the product is abnormal during use, you can do the following:

Test E-Shock Feature

- Power on
- Make settings
- Blow into sound sensor
- Attach light testing unit to probes
- Look for LED to light up

* LED will not light if E-Shock setting is 0.

Restore Factory Settings — When the product fails, reset the product to solve the problem.

Check Collar Wearing — Make sure the collar is tight enough and the device is in the correct position.

Increase Sensitivity — Contact Dealer

BARK TRAINING COLLAR
USER MANUAL
TC-001/TC-002B

The design concept of this product is to cultivate good habits of pets, not punitive. Do not overuse this product on pets.

Made in China

First Time Using

- The default setting of this product is: sensitivity sensor level 6 , vibration level 3 , electric shock (abbreviation : E-Shock) level 0 . If you don't need the E-Shock to be activated, you don't need to make any settings.
- Fully charge the battery before using the first time. In standby mode, touch the button Ⓜ to view the charge level (more details please see page 9 Battery Power).

Tip: Please read the user manual carefully before use and keep it in a safe place!

Warning

- Product wearing time is recommended no more than 12 hours/day.
- For pets ranging from 5kg~50kg (11lbs~110lbs) and neck circumference up to 62cm (25in). Not suitable for dogs less than 5kg (11lbs) or younger than 6 months.
- Children should not play with this product. Keep it away from children.
- When the power is turned on, the human body should not directly touch the E-Shock terminal.

Contents

Bark Training Device & Nylon Collar — User Manual

USB Charging Cable — E-Shock Probe — Test Unit & Driver For Probes

Bark Training Device	1
User Manual	1
Nylon Collar	1
USB Charging Cable	1
E-Shock Test Unit	1
E-Shock Probe	2 Pairs

Introduction

Bark Collar Components

Buckle — Slider Buckle — Adjustable Strap — E-Shock — Vibration — Sensitivity — LED Display — Enter Setting Mode / Adjust Level — Power ON&OFF/ Checking / Switch Mode

Reset — USB Charging — E-Shock Probe — Sound Sensor — Test Contact — Test Light

Basic Features

One Trigger Methods

Sound Trigger — 1~7 level sensitivity. Default setting is 6.

2 Working Modes

- Sleeping Mode — No barking for 5 secs, sleep mode begins.
- Training Mode — Dog is barking, training mode activated.

3 Basic Training Methods

- Beep — Always exists and cannot be cancelled. No level setting.
- Vibration — 0~7 level output settings, 0 is off. Default is level 3.
- E-Shock — 0~7 level output settings, 0 is off. Default is level 0.

How Does the Device Work?

Working Status & Status Tips

- Beep Training — Make Sounds — lasts 2 secs
- Vibration Training — Display
- E-Shock Training — Display

How To Trigger

Dog Barking → Sound Triger → Features are activated

Sensitivity Determines Trigger Point

Barking volume → Sensitivity Level → Triggered by Level

How Does the Device Work?

Training Method Execution Order

* This means that with both vibration and shock functions turned on, your dog will hear the beep first , then vibration will occur, then shocking will occur.
* Execution order does not change after vibration and E-Shock are turned off.

4 Training Methods Combination

- Turn OFF Vibration & E-shock
- Turn OFF E-shock
- Turn OFF Vibration
- Turn ON All

* Vibration and E-Shock can be turned off by setting 0.

How Does the Device Work?

How Does Combination Work

CYCLE / SUSPEND

Single Trigger, Single Group — Trigger Continuously, Output Continuously 7 Times & Break Loop

1 min Pause

* For protection, there is a 1-minute pause after 7 Combination triggers, regardless if the dog is still barking.

Dog Wearing

Applicable Dog Range

- Dogs Must Be Healthy — Please make sure your dog is healthy before using the product. Please consult a veterinarian.
- Aggressive Dogs are Prohibited. — For aggressive dogs, use is prohibited. Otherwise, it may cause potential bites to humans.
- Body Weight & Age — This product is suitable for dogs over weighing more than 8 pounds and the age of 6 months.
- Long & Short Hair — Long-haired dogs can moderately shorten the hair at the throat, but shaving is not recommended.

Product Assembly

Select Probes → Mount Probes → OK!

Dog Wearing

Fit for Wearing

Adjust for Dog's Neck — Excess Strap Slider Buckle — Maximum Circumference

Key Points for Fine Working

Vocal Cord Position — Collar Tight Enough — Good Skin Contact

Comfort & Skin Healthy

Moderately Tight — Skin Contact Just Fine — Don't Wear More than 12H

Timely Adjustment — Daily Check for Rash&Sore. — Keep Contacts Clean