

Product Description

A: Gas Inlet: Relenish Spray Agent B: Spray Nozzle: Spray Gas to stop barking C: Audio Sensor: Receiver sound to trigger spray. D: Charge Port: USB cable for charging E: Power Button: Turn on/ off. F: LED1. indicator light 1 G: LED 2, indicator light 2 H: Adjust button: 1. Adjusting spray volume: Small/ Large 2. Adjusting sensitivity: Low/ High



Operation Description

1. Turn on (PT1)

Long press Power button for 3 seconds, LED1 flash one time, and LED2 light up for on second in blue and purple color.

2. Turn off (PT1) Long press Power Button for 3 seconds. and the LED1 flash 3 times in vellow color.



3. Sprav Adjustment (PT2)

- volume of spray.

- sensitivity.

Gas Charging Description

1. Gas charging indication

LED2 blue and vellow color flash 5 times every 10 seconds.

2. Gas charging process

Step1: Turn off the device Step2: Insert the gas cylinder vertically into the gas inlet,

Step3: Gas charging for 10 seconds. 3. How many times of spray after full

charging gas?

A: Small Volume: About 60 times. B: Large Volume: About 30 times.



Kindly Reminder

A small number of dogs will display irritablity when wearing a spray bark stopping device, and confused about spray warnings or uncertain how to avoid, you need to gently guide and comfort your pet, use proper methods to guide the dogs to adapt to spray warnings. After your guidance several times, the dog will adapt quickly.

1. The device is suitable for all large, medium and small dogs and shall no be used for any other purpose not described in this manual.

2. Too long time use of the device on the dogs, it will cause a condition. similar to bedsore, ie. Compressive skin necrosis, to reduce this possibility, please refer to following method; · 6 ·

A: Regularly check if there is any rash or pain anywhere on the neck of the dogs.

B: Please monitor your dog within the first two davs.

C: Make real time inspection of the device to prevent excessive pressure, and one finger should be able to be placed between the device and the dog's neck.

D: Regularly scrub around the dog's neck and the device's sensor head weekly.

E: Do not attempt to remove or repair any parts of the device, which otherwise will make the warrantv invalid.

· 7 ·

G: We recommend the use of this device for dogs aged 6 months and weight over 8 pounds. H: This device should not be used continuously for 12hours with 24 hours.

(ſ		Ì
	0		

Press adjust button one time to adjust the 1. Small Volume: LED2 flash in vellow light. 2. Large Volume: LED2 flash in blue light.

4. Sensitivity Adjustment (PT3)

Press adjust button three times to adjust the

1. Low sensitivity: LED1 and LED2 flash one time, 2. High sensitivity: LED1 and LED2 flash twice.



F: If your dog has extreme resistance or dangerous movement against wearing this device, stop using it immediately after the guidance is invalid.

Testing Tips

Turn on the device and "shout in a row" at the receiving hole on the back of it, if it sprays, it is workable.

- 8 -

Charging Description

1. Low power indication: LED1 red light flash every 5 seconds, it indicates low power, need to be charged.

2. Charging Status

A: Charging, LED1 light up red light. B: Full charge, LED1 light up green light.

3. Charging Conditions

A: Micro USB charging plug B: The following devices can be used for charging. mobile phone charger, computer, etc.



How to wear the collar



1. Wear the collar on the dog's neck, adjust the collar belt according to adjust the collar belt according to the size of the neck of your dog, and remove the remaining part of the collar. Collect wearing is the collar. Collect wearing is the prerequisite for effective use.



2. If you dog with long hair, it is necessary to trim the hair on the spray path to ensure that the mist can be sprayed to an effective range.

. 9 .

 \sim

3. Make sure the spray nozzle aligned perpendicularly to the dog's nose, and criterion wearing is based on the extent that one finger can be accommodated between the collar and the dog's neck. this can accurately identify the frequency of the dog's barking. Correct Installation is very important, too much relaxation of the device will lead to uncoordinated action and affect the normal operation of the product

