

# **Booster Bath**®

## Medium Assembly Instructions

Tools Needed: Phillips head screwdriver



1  
Push 12 rubber bumpers into receiving holes in the bottom of each Booster Pedestal.



2  
Install Booster Pedestals to legs as shown.



3  
Attach legs as shown. **Note:** Make sure that legs marked with “A” are attached in the front of the Booster Bath. Legs marked “B” are designed to attach at rear.



4  
Push drain hose on, as shown. Flip tub upright when complete.



5  
Install 4 mat clips using 8 small screws.



6  
Install Shampoo Caddy in rear wall of tub.



7  
Place leash restraint in T-formation.



8  
Place plastic washers over steel eyehooks. Push eyehook through hole in sidewall of tub and screw on plastic knob firmly.



For any questions or concerns please contact us at [info@boosterbath.com](mailto:info@boosterbath.com)



Dear Valued Customer,

With the purchase of your Booster Bath you have now conquered the three most difficult aspects of home grooming: elevation, containment, and drainage. You will now enjoy 360-degree access while eliminating slipping and sliding, chasing the shampoo bottle, backaches and messy bathroom clean up. Bathing can now be transformed from a dreaded chore to a bonding experience for both you and your dog!

### Helpful Tips:

1. Your triple leash restraint will arrive to you in the adjusted long position. We recommend you reduce it to the shortest position and lengthen if necessary depending on breed size.
2. After setting up your Booster Bath, encourage your dog to enter and exit the tub a few times before bathing. You may want to have treats on hand and always remember to praise him or her for good behavior.
3. Of course, we do not recommend using cold water when bathing your pet. When first applying water, start at their paws, this allows them to feel that warm water is being used.
4. When it is time to rinse out the shampoo, rinse it out thoroughly.
5. It is always a good idea to wash their head last, as this will reduce shaking.
6. Never spray water into your pets ears, this may cause potential ear infections. To avoid this, when rinsing cup your hand over the ear or simply pinch ears shut with your hand.
7. Always dry your pet thoroughly in the Booster Bath. We recommend having 2 towels on hand before you begin.
8. Never leave your pet unattended in your Booster Bath!



**A Clean Pet Is A Happier Healthier Pet!**

You may also visit our site at: [www.boosterbath.com](http://www.boosterbath.com)



**For any questions or concerns please contact us at [info@boosterbath.com](mailto:info@boosterbath.com)**



#### Medium Parts List

Item #	Name	Materials	Quantity
1	Instruction Sheet	Paper	1
2	Star Knobs	Plastic / Stainless center	3
3	Mat Retainer	Grey Plastic (PP)	4
4	Grey Eyehook Washer	Grey Plastic (PP)	3
5	Screw: Flat 8 - 5/8 SMS	Stainless Steel (SS)	8
6	Round Leg Bumper	Black Rubber	12
7	Medium Restraint	Polyester	1
8	Mat - Medium	Grey Foam	1
9	Fan Nozzle (Grey)	Grey Plastic (PP)	1
10	Drain Hose, 5 Feet	Grey Plastic (PP)	1
11	Pedestals	Grey Plastic (PP)	4
12	Legs	Grey Plastic (PP)	4
13	Shampoo Caddy	Grey Plastic (PP)	1

**If any parts are missing or damaged or for warranty service please contact Booster Bath. Do not contact the retailer.**

Booster Bath  
888-300-5139  
CustomerService@BoosterBath.com  
<http://www.BoosterBath.com>