



MODEL  
**#5529**

# Universal Small Animal Home/ Bungalow **ASSEMBLY**

Instructions online at [www.prevuepet.com](http://www.prevuepet.com)

## CUSTOMER SUPPORT


Please contact Prevue Pet Products:

**PHONE** 1 (312) 243-3624


**ONLINE** [www.prevuepet.com](http://www.prevuepet.com)

**EMAIL** [customerservice@prevuepet.com](mailto:customerservice@prevuepet.com)

## 1 PIECES



**B**




**L**

**R**

interchangeable




A total of 18 connectors are included. Sixteen are to be used on the cage, with two included as extras.



- Insert the **connector** between the panels and twist 90°.

- Flip the connector up and click it onto the vertical wires, above and below the horizontal wire.




- Connect **all panels** together with the **connector clips**; four along each corner seam.



Make sure the front panel is assembled so that the door opens out.


Heavy vertical wires face cage exterior

## 2 PIECES




- Set the assembled cage into the **base**, making sure all bottom wire is positioned between the outer rim and inner raised tabs.

# 3 PIECES




- Add corner clips over the corner seams.




- Hook the **base clips** onto the cage wire and clip them down under the base rim.  
One clip on each end; two each along the front and back.


# 4 PIECES



- Hook the **ramps** onto the **platforms** first.
- Insert the **platforms** into the cage (lower platform/ramp first). Set the extended tabs over horizontal wires at an equal height along the front and back. Push tabs down onto the wire to lock the platform in place.




# 5 PIECES




- Set the **roof** on the corners, and arrange the extended wires as detailed:



- **UNDER** the cage body



- **UNDER** the cage body



- **OVER** the cage body



Assembly completed.